



Wall: Timber construction *Airtight on the inside*

Base joint inside



Initial situation:

- Wooden wall installed



- Clean the substrates to be bonded
- Apply Dockskin 200
- Use a roller to apply thinly and over the entire surface of the concrete floor
- Wait until Dockskin 200 is completely dry



- Roll out Fentrim to required length
- Add approx. 15–20 cm extra on both sides
- Cut Fentrim to required length



- Remove about 10 cm of 1st backing strip and stick to wooden wall
- Allow approx. 15–20 cm to extend to left and right

Wall: Timber construction *Airtight on the inside*



- Remove 1st backing strip little by little
- Align and fix tension-free
- Press on firmly



- Remove the remaining backing strip little by little
- Apply without introducing tension
- Press on firmly



How it should look:

- Wooden wall is joined to concrete floor



Dockskin® 200

P. 138

Fentrim® 330 grey

P. 139