



Roof *Airtight on the inside*

Skylight joint



- Cut vapour control layer




- Cut vapour control layer to reveal depth



- Affix Corvum to vapour control layer with the folded edge flush with the sheet edge
- Press on



- With the backing strip folded back insert Corvum accurately into the groove, **affix Corvum all the way to the corner**
- Successively remove backing strip
- Press on



- Mount the remaining vapour control layer sheets: Cut sheet to size
- Affix Corvum with the folded edge flush with the sheet edge on three sides




- With the backing strip folded back insert Corvum accurately into the groove
- **Affix Corvum all the way to the corner**
- Successively remove backing strip
- Press on



- Seal the sides



- Cut out 90° angle pieces from 4 short pieces of Corvum
- Seal the corners



Roof

Airtight on the inside



- Finally seal the overlaps using Sigrall 60



How it should look:

- Skylight permanently airtightly sealed with Corvum 30/30 and Sigrall 60



Corvum® 30/30

P. 124